

## #25639 BEACH GNOME SPINNER ASSEMBLY INSTRUCTIONS

1. Remove gore panels from package and unfold. Make sure that the lower edge binding tape is not twisted or bunched. (Diagram A)
2. Slide the Main Rotating Assembly through the center of the ring of gore panels with the support struts all facing up and curved in the same direction. (Diagram B)
3. Insert the gore struts into the strut holes on the top disc of the Main Rotating Assembly. (Diagram C)
4. Insert the Vertical Umbrella Strut into the Body Frame Upper Ferrule. Use the Velcro Access Opening to help you make the Upper and Lower Ferrule connections (Diagram D).
5. Insert the Lower Support Pole into the Body Frame (Diagram E).
6. Drive Ground Stake into ground. Slide Lower Support Pole into Ground Stake. (Diagram F)

**PLEASE NOTE:** Although your Garden Spinner is constructed with UV resistant SunTex™ fabric, to preserve its durability, we recommend taking the Spinner inside during harsh weather or when not in use.

