# FUN FLYER DELTA KITE

# **FLYING INSTRUCTIONS**

# PREPARATION:

- Slide the struts down to the end of the sleeve.
- Insert the across strut into the pockets at the leading edge.
- Attach your line to the tow point.

# **LAUNCHING:**

- Have a friend stand about 75 feet downwind from you and holdt he kite with its nose pointed towards the sky.
- As the wind catches the kite, signal your friend to release the kite while you pull in the line with long steady pulls.
- As the kite flies upward, slowly let out more line.




### FLIGHT:

- Your Fun Flyer Kite has been designed for optimum stability in a broad range of wind conditions.
- If it should go into a dive, immediately let out a little line and the kite will swing out of the dive.
- If the kite drops during a lull in the wind, pull in the line to keep it aloft.

### **SAFETY MEASURES:**

- Select a wide open area to fly your kite.
- Never fly your kite near power lines and busy streets or over spectators and crowds.





CAUTION: DO NOT FLY YOUR KITE NEAR POWER LINES, BUSY STREETS, CROWDS





Made in China Primus Inc. Hyattsville, Maryland



Note: Wind conditions aloft may vary considerably from those found near ground leve

