Assembly Instructions

Step 1

Slide one Nylon Washer onto the Horizontal Axle.

Step 2

Slide on Wings and second Nylon Washer. Attach End Cap.

Step 3

Slide the narrow tip of Upper Support Pole into Hub. Push the Support Pole firmly down until it locks into place and cannot be removed. This is best done with the base of the Upper Support Pole on a hard surface and pushing the pole into place.

Step 4

Connect Upper Support Pole with Lower Support Pole and insert into the ground.

Compatible with Premier's 6 mm Deck Mount (sold separately).



