

Accent Flags

by premier designs

House and Garden Flag Display Rack Assembly Instructions

- 1) Assemble Frame pieces as shown at left.
- 2) Clip Basket onto Frame using Basket Hooks. Basket can be attached to either right or left side of Frame.
- 3) Clip Flag Hooks onto lower horizontal bars of Frame. Flag Hooks can be positioned on Frame as needed to suit your individual display needs.
- 4) Insert Arms into Arm Holes along top and side horizontal bars on Frame. Arms should line up as straight and evenly as possible. Bend arms as needed to achieve an appearance similar to the one shown at left.





Premier Designs

Hyattsville, Maryland USA

www.premierkites.com

