


Spinner Axle First, slide Spinner Axle onto Strut Assembly Second, tighten knob on "T" Joint



PLEASE NOTE: Although your Horse and Buggy Spinner is constructed with UV resistant SunTex™ fabric, it is recommended that you take it inside during storms and harsh weather to preserve its durability.

Step 1

The Strut Assembly of your Horse and Buggy spinner is shipped in four sections. Connect Center Rod of the Rear Strut Assembly to the Center Rod of the Center Strut Assembly. Open Velcro straps and insert Strut Assembly into bottom of Horse and Buggy Body Sleeve as shown. Make sure all internal body struts are connected to the strut assemblies. (diagram A)

Step 2

Attach the Center Strut Assembly to the Front Strut Assembly that is already inside the Body Sleeve. You will have to bend the Body Sleeve to fit the Strut Assembly together. (diagram B)

Step 3

Take one of the Spinner Axles and slide it onto the Rear Strut Assembly at back of Horse and Buggy Body. Tighten the knob on the "T" Joint to hold the Axles to the Struts. (diagram D)

Step 4

Take one of the four Spinner Wheels and slide it onto one of the two Spinner Axles. Slide second Spinner Wheel onto Spinner Axle. (Note: Spinner Wheels on same side of Horse and Buggy should spin in same direction and Spinner Wheels on same axle should spin in opposite directions. Before putting second Axle Cap into place, make sure wheels spin as shown in diagrams E and F.) Pound second Axle Cap onto uncapped end of Spinner Axle using a mallet or piece of wood. (diagram E)

Step 5

Repeat Step 4 using second Spinner Axle and the two remaining Spinner Wheels to assemble front Spinner.

Step 6

Pound Ground Stake into ground and insert non-ferruled end of Support Pole into Ground Stake. Insert Upper Pole Section of completed Horse and Buggy Spinner into ferrule on top of Support Pole. (diagram F)

